Country Club Fire Place Operation

The Fire Place main switch & remote control are located on the wall beside the fire place.

- 1. Turn the Fire Place main switch ON.
- 2. Point the Remote Control at the Fire Place and press Obutton, once only.
- 3. The fire place will automatically start after several minutes. Please be patient.
- 4. When finished, ensure to turn the fire place off by pointing the Remote Control at the Fire Place and press Button, once only.
- 5. Turn the Fire Place main switch OFF
- 6. It will take several minutes for the fire to stop burning.
- 7. Please wait until the fire has gone out, before leaving the area. (for safety reasons)

If you have any questions or would like a demonstration, please contact the Resort Office.